

故障代碼（PCODE）清單

序號	故障碼	說明（UAES）	Description
1	P0107	進氣壓力感知器接地短路	Manifold Abs. Pressure or Bar. Pressure Low Input
2	P0108	進氣壓力感知器開路或對電源短路	Manifold Abs. Pressure or Bar. Pressure High Input
3	P0112	進氣溫度感知器接地短路	Intake Air Temp. Circ. Low Input
4	P0113	進氣溫度感知器開路或對電源短路	Intake Air Temp. Circ. High Input
5	P0117	引擎溫度感知器接地短路	Engine Coolant Temp. Circ. Low Input
6	P0118	引擎溫度感知器開路或對電源短路	Engine Coolant Temp. Circ. High Input
7	P0122	節氣門位置感知器接地短路	Throttle Pos. Sensor Circ. Low Input
8	P0123	節氣門位置感知器開路或對電源短路	Throttle Pos. Sensor Circ. High Input
9	P0130	含氧感知器信號不合理	O2 Sensor Circ. Malfunction
10	P0131	含氧感知器信號電路接地短路	O2 Sensor Circ. Low Voltage
11	P0132	含氧感知器信號電路對電源短路	O2 Sensor Circ. High Voltage
12	P0134	含氧感知器電路開路	O2 Sensor Circ. No Activity Detected
13	P0201	噴油嘴控制電路開路	Cylinder 1- Injector Circuit
14	P0261	噴油嘴控制電路接地短路	Cylinder 1- Injector Circuit Low
15	P0262	噴油嘴控制電路對電源短路	Cylinder 1- Injector Circuit High
16	P0321	引擎轉速感知器信號參考點故障	Engine Speed Reference Mark
17	P0322	引擎轉速感知器脈衝信號(開路、短路)	Eng. Speed Inp. Circ. No Signal
18	P0508	怠速控制系統驅動接地短路	ISA control Circuit Low
19	P0509	怠速控制系統驅動對電源短路	ISA control Circuit High
20	P0511	怠速控制系統驅動接腳開路	ISA control Circuit/Open
21	P0560	系統電瓶電壓信號不合理	System Voltage Malfunction
22	P0562	系統電瓶電壓過低	System Voltage Low Voltage
23	P0563	系統電瓶電壓過高	System Voltage High Voltage
24	P0650	警示燈檢測電路故障	Malfunction Indicator Lamp Control Circ.
25	P1116	引擎溫度過溫	